

ASSEMBLY INSTRUCTIONS

GREEN LANTERN - SIXTH SCALE FIGURE

ATTENTION: PLEASE USE CAUTION DURING ASSEMBLY


FOR FURTHER ASSISTANCE:

CALL US (WITHIN U.S.): 1-855-SIDESHOW

CALL US (OUTSIDE U.S.): 1-805-214-2157



To enable the light-up feature, twist off the bottom piece of the Power Battery Lantern. Remove the white paper tab and screw piece back on.




To switch on the light-up Power Battery Lantern, tap the Green Lantern logo. Tap again to switch off.



POWER BATTERY HOLDING HAND
STEP 1: Gently pull outward on Power Battery Lantern handle to remove it.



STEP 2: Feed handle through holding hand.



STEP 3: Reattach handle to the Power Battery Lantern.

READ THE INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT

Product uses two (2) LR44 batteries for the Power Battery (located in the bottom of the Power Battery)

1. Non rechargeable batteries should not be charged.
2. Do not mix different types of batteries.
3. Do not mix new and used batteries.
4. Only the recommended type of batteries should be used.
5. Batteries should be inserted and oriented with the correct polarity.
6. Exhausted batteries should be removed from the product.
7. The battery terminals must not be short-circuited.
8. Batteries should be disposed in an appropriate place.
9. Remove batteries when not in use or discharged.



SIDESHOW

SIDESHOW.COM/Instructions