

ASSEMBLY INSTRUCTIONS

© 2011 Warner Bros. Entertainment, Inc. All Rights Reserved. Superman, Batman, and Doomsday are trademarks of Warner Bros. Entertainment, Inc. All Rights Reserved.

ASSEMBLY INSTRUCTIONS

© 2011 Warner Bros. Entertainment, Inc. All Rights Reserved. Superman, Batman, and Doomsday are trademarks of Warner Bros. Entertainment, Inc. All Rights Reserved.



REMOVAL INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

© 2011 Warner Bros. Entertainment, Inc. All Rights Reserved. Superman, Batman, and Doomsday are trademarks of Warner Bros. Entertainment, Inc. All Rights Reserved.

ASSEMBLY INSTRUCTIONS

© 2011 Warner Bros. Entertainment, Inc. All Rights Reserved. Superman, Batman, and Doomsday are trademarks of Warner Bros. Entertainment, Inc. All Rights Reserved.



NOTICE

This product contains a lot of small fragile parts, which may dislocate or move during shipment. Should you notice this during assembly, we advise to carefully feel out the specific dislocated part with a finger or pin, leaving for about 45-60 seconds from a 10 cm distance. When done, carefully adjust the part to the correct position, and it will be fixed.

本產品包含大量的小型脆弱零件，在運輸過程中可能會鬆動或移位。如果您在組裝時發現此情況，我們建議您用手指或針輕輕觸摸鬆動的特定部位，距離約10厘米，靜置45-60秒鐘。完成後，請將零件調整到正確的位置，它就會固定好。

本產品包含大量的小型脆弱零件，在運輸過程中可能會鬆動或移位。如果您在組裝時發現此情況，我們建議您用手指或針輕輕觸摸鬆動的特定部位，距離約10厘米，靜置45-60秒鐘。完成後，請將零件調整到正確的位置，它就會固定好。