STAR WARS ATTACK OF THE CLONES

WARNING
"This product contains a Button Cell Battery.
A swallowed Button Cell Battery can cause internal chemical burns and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention."

Please keep this instruction sheet for future reference. (ご参考のため、説明書は保管してください。)
(説明書は、大切な情報が記載されていますので、お捨てになる前にお子様の目に触れないところに保管してください。)

BATTLE DROID™
(DROIDEKA)
1:6TH SCALE COLLECTIBLE FIGURE

INSTRUCTION SHEET

©2020 Lucy Fox Limited. All Rights Reserved.
www.hottoys.com.hk www.sideshow.com

Disney



A. C-3PO MECHANICAL HEAD / C-3POのヘッドについて / C-3PO机械头部

Three batteries (AG13/LR44, 1.5V) are included. Open the cover to put in new batteries. Activate the light-up function by turning the on/off switch.
随附以上电池(AG13/LR44, 1.5V)共3粒。请开盖更换电池。打开/关闭开关来启动发光功能。
随附以上电池(AG13/LR44, 1.5V)共3粒。请开盖更换电池。打开/关闭开关来启动发光功能。

B. INTERCHANGEABLE HEAD / 差し替え用ヘッドについて / 可替换头部



Two styles of head could be interchangeable as shown.
随像的两款可替换的头部。
如图所示随像的两款可替换头部。

C. BACKPACK ACCESSORIES / バックパックについて / 背包配件

Attach the indicated part to hold the blaster rifle on the backpack.
随像的零件安装在背部，固定住相应武器。
如图所示将指定部件，固定住相应武器。

D. EQUIPPING BACKPACK / バックパックの差し替えについて / 安装背包



Remove indicated parts on the back to equip backpack with extendable antennas.
随像的零件取下，换上带有伸缩天线的背包。
如图所示将指定部件拆下，换上带有伸缩天线的背包。

E. EQUIPPING ANTENNA SET / アンテナの差し替えについて / 安装天线组

Remove indicated parts to attach the antenna set.
随像的零件取下，换上带有天线的零件。
如图所示将指定部件拆下，安装天线组。

F. HOLDING ACCESSORIES / 付属品/武器・アクセサリーについて / 使用配件

The hands can be used to hold the blaster rifle or binoculars as shown.
随像的手可握住武器或望远镜。
如图所示随像的手可握住武器或望远镜。

G. TRANSPORT MODE PREPARATIONS / 格納モードへの変更について / 运输模式准备

Remove and attach indicated parts as shown.
随像的零件拆下，换上指定零件。
如图所示拆下及安装指定部件。

H. TRANSPORT MODE / 格納モードについて / 运输模式

Push hand into body of the figure as shown. Bend legs and arms to position as shown to enter transport mode.
随像手伸进，腿和手臂弯曲，放入指定位置，即可进入运输模式。
如图所示将人物手伸进身体，腿部和手臂弯曲到指定位置，即可进入运输模式。

I. FIGURE STAND / 特製台座について / 相装地台



Figure peg can be attached to figure base as shown.
随像支撑杆可安装在底座上。
如图所示将人物支撑杆安装在底座上。

IMPORTANT | ご注意 | 重要

Mechanical gears may get damaged if mishandled. Please handle with care.
机械齿轮若操作不当，可能会受损。请小心操作。
如果不当操作，齿轮可能会受损。请小心操作。

WARNING • Do not mix old and new batteries or batteries of different types(alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. • Do not charge non-rechargeable batteries. • Rechargeable batteries are only to be charged under the supervision of an adult. • Do not short circuit the battery terminals. • Insert batteries correctly and parts assemble should be done by an adult. • Batteries are to be inserted with the correct polarity and exhausted batteries are to be removed from the product. • Do not look at the LED light directly. It may be harmful to eyes. • Change the batteries and observe the status of batteries regularly to avoid leakage which may cause damage to the product and its electricity system. • Never short-circuit the battery terminals. Note: The above situations are not included in maintenance-not-replacement

警告・请勿混用新旧电池或不同类型的电池。碱性电池、标准（碳-锌）电池或充电（镍-镉）电池。・请勿给非充电电池充电。・在充电时请成人监督。・请勿短路电池电池端子。・请正确安装电池，并从产品中取出耗尽的电池。・不要直视LED灯。它可能对眼睛有害。・定期更换电池并观察电池状态，以免漏电造成产品及其电子系统。・切勿短路电池端子。重要：若有以上情况发生，本品将不负责修理或更换。

©2020 Lucy Fox Limited. All Rights Reserved.